



How to Use a Plumbers Puller™

Model No. 03875

Handle Puller

Turn off the water.

Turn the T-bar handle of the puller tool up until the tip clears the handle. Place the arms under the faucet handle and hold the grip bar firmly while turning the threaded system down into the screw hole until the faucet handle is free.

Compression Sleeve Puller (1/2" copper)

Turn off the water and remove the angle stop.

Insert the sleeve puller into the copper tubing.

Insert the peg of the faucet puller into the hole and place the puller jaws behind the compression nut.

Turn the puller handle and remove the nut and sleeve just like you would pull a faucet handle. Some tapping of the puller may be necessary to completely remove the sleeve and nut.



Lifetime Guarantee